| Drawing No. | Rev. | Page |
|--------------|------|--------|
| NHL-5FV2-W18 | F | 1 / 10 |

SPECIFICATIONS

Product Name: Network Monitor Signal Tower with MP3

Model: NH□-□FV2□-□□□□□

PATLITE Corporation

| Drawing No. | Rev. | Page |
|--------------|------|--------|
| NHL-5FV2-W18 | F | 2 / 10 |

1. General Specifications


| | 5 tiers | NHL-5FV2 | NHP-5FV2 | |
|---|--|--|--|--|
| | 4 tiers | NHL-4FV2 | NHP-4FV2 | |
| Model | 3 tiers | NHL-3FV2 | NHP-3FV2 | |
| | 2 tiers | NHL-2FV2 | NHP-2FV2 | |
| 1 tier | | NHL-1FV2 | NHP-1FV2 | |
| Rated V | oltage | 24VDC (Main Unit) | | |
| | AC Adaptor | Input: 100VAC - 240VAC (50/60Hz) Output: 24VDC | | |
| Operating Vo | tage Range | Rated Volta | age ±10% | |
| Rated Power | Main Unit | Standby: 2.2W Maximum: 3.5W | (with AC Adaptor, 100VAC input) | |
| Consumption | LED Unit | 1.0W (g | per Unit) | |
| Operating Ambie | nt Temperature | 0°C - +40°C (No E | ew or Condensation) | |
| Operating Amb | ient Humidity | 20% - +80% RH (No | Dew or Condensation) | |
| Storage Ambier | t Temperature | -10°C - +60°C (No | Dew or Condensation) | |
| Storage Ambi | | 20% - +80% RH (No | Dew or Condensation) | |
| Mounting | | Indoo | , | |
| Mounting | | | ight | |
| Protection | | | 20 | |
| Insulation F | | More than 10MΩ at 500VDC between live p | art and non-current carrying metallic part *1 | |
| | | | between live part and non-current carrying | |
| Withstand | Voltage | metallic part without t | , | |
| Mass | 5 tiers | 1270g | 1085g | |
| (Tolerance | 4 tiers | 1210g | 1050g | |
| ±10%) | 3 tiers | 1150g | 1015g | |
| (AC Adaptor | 2 tiers | 1090g | 980g | |
| not include) | 1 tier | 1030g | 945g | |
| Outer Din | | Refer to the Outer Dimension Drawing | | |
| Sound Pres | | 88dB or more | | |
| Environmental | | | | |
| Condition | | MP3 data of the content and use of the enviro | , , , | |
| Audio Lin | | 600Ω OdBy (Unbalanced, Monaural Mini-Jack) | | |
| Communicat | | Ethernet (Conforms to the IEEE 802.3) | | |
| (LA | | 10BASE-T / 100BASE-TX (Auto negotiation, Full Duplex / Half Duplex) | | |
| Interface | USB Port | USB2.0 / 1.1 Type-A 1ch (For USB Memory) | | |
| | | Non-voltage contact output | | |
| External Cor | | | | |
| External Cor | tact Output | | | |
| Num | tact Output ber of Contacts | Non-voltage o | contact output I | |
| Num Co | tact Output ber of Contacts ntact Capacity | Non-voltage of (30VDC @ 3A) inrush current 5A or less | contact output 1 (5VDC @ 1mA , Minimum, Reference) | |
| Num Co V | tact Output ber of Contacts ntact Capacity /ire Diameter | Non-voltage of (30VDC @ 3A) inrush current 5A or less Solid Wire / Stranded Wire: φ | contact output (5VDC @ 1mA , Minimum, Reference) 0.41 - 0.81mm (AWG26 - 20) | |
| Num Co V | tact Output ber of Contacts ntact Capacity /ire Diameter /iring Method | Non-voltage of (30VDC @ 3A) inrush current 5A or less Solid Wire / Stranded Wire: φ Screwless to | contact output (5VDC @ 1mA , Minimum, Reference) 0.41 - 0.81mm (AWG26 - 20) erminal block | |
| Num Co V W External Co | tact Output ber of Contacts ntact Capacity //ire Diameter //iring Method ntact Input | Non-voltage of (30VDC @ 3A) inrush current 5A or less Solid Wire / Stranded Wire: ϕ Screwless te Non-voltage contact in | contact output (5VDC @ 1mA , Minimum, Reference) 0.41 - 0.81mm (AWG26 - 20) erminal block uput NPN Transistor | |
| Num Co V W External Co | tact Output ber of Contacts ntact Capacity /ire Diameter /iring Method | Non-voltage of (30VDC @ 3A) inrush current 5A or less Solid Wire / Stranded Wire: ϕ Screwless to Non-voltage contact in | contact output (5VDC @ 1mA , Minimum, Reference) 0.41 - 0.81mm (AWG26 - 20) erminal block uput NPN Transistor | |
| Num Co V V External Co Num | tact Output ber of Contacts ntact Capacity //ire Diameter //iring Method ntact Input | Non-voltage of (30VDC @ 3A) inrush current 5A or less Solid Wire / Stranded Wire: ϕ Screwless to Non-voltage contact in "ON" output current @ | contact output (5VDC @ 1mA , Minimum, Reference) 0.41 - 0.81mm (AWG26 - 20) erminal block put NPN Transistor 4 6mA or less per cannel | |
| Num Co V V External Co Num Co | tact Output ber of Contacts ntact Capacity /ire Diameter /iring Method ntact Input ber of Contacts | Non-voltage of (30VDC @ 3A) inrush current 5A or less Solid Wire / Stranded Wire: \$\phi\$ Screwless to Non-voltage contact in "ON" output current @ Terminal OFF condi | contact output (5VDC @ 1mA , Minimum, Reference) 0.41 - 0.81mm (AWG26 - 20) erminal block put NPN Transistor 6mA or less per cannel tion Voltage: 24VDC | |
| Num Co V W External Co Num Co | tact Output ber of Contacts ntact Capacity fire Diameter firing Method ntact Input ber of Contacts ntact Capacity | Non-voltage of (30VDC @ 3A) inrush current 5A or less Solid Wire / Stranded Wire: \$\phi\$ Screwless to Non-voltage contact in "ON" output current @ Terminal OFF conditions Solid Wire / Stranded Wire: \$\phi\$ | contact output (5VDC @ 1mA , Minimum, Reference) 0.41 - 0.81mm (AWG26 - 20) erminal block put NPN Transistor 4 6mA or less per cannel tion Voltage: 24VDC 0.41 - 0.81mm (AWG26 - 20) | |
| External Co Num Co Num Co V V V V V V | tact Output ber of Contacts ntact Capacity fire Diameter firing Method ntact Input ber of Contacts ntact Capacity fire Diameter firing Method | Non-voltage of (30VDC @ 3A) inrush current 5A or less Solid Wire / Stranded Wire: \$\phi\$ Screwless to Non-voltage contact in "ON" output current @ Terminal OFF conditions Solid Wire / Stranded Wire: \$\phi\$ Screwless to Screwle | contact output (5VDC @ 1mA , Minimum, Reference) 0.41 - 0.81mm (AWG26 - 20) erminal block put NPN Transistor 4 6mA or less per cannel tion Voltage: 24VDC 0.41 - 0.81mm (AWG26 - 20) erminal block | |
| Num Co V External Co Num Co V V Operating | tact Output ber of Contacts ntact Capacity /ire Diameter /iring Method ntact Input ber of Contacts ntact Capacity /ire Diameter /iring Method portion | Non-voltage of (30VDC @ 3A) inrush current 5A or less Solid Wire / Stranded Wire: \$\phi\$ Screwless to Non-voltage contact in "ON" output current @ Terminal OFF condit Solid Wire / Stranded Wire: \$\phi\$ Screwless to Screwless to Screwless to "Volume", "Reset" Switch, "Clear" \$\frac{1}{2}\$ | contact output (5VDC @ 1mA , Minimum, Reference) 0.41 - 0.81mm (AWG26 - 20) erminal block put NPN Transistor 6mA or less per cannel tion Voltage: 24VDC 0.41 - 0.81mm (AWG26 - 20) erminal block witch, "Mode" Switch, "Test" Switch | |
| Num Co V W External Co Num Co V V Operating | tact Output ber of Contacts ntact Capacity fire Diameter firing Method ntact Input ber of Contacts ntact Capacity fire Diameter firing Method portion ories | Non-voltage of (30VDC @ 3A) inrush current 5A or less Solid Wire / Stranded Wire: \$\phi\$ Screwless to Non-voltage contact in "ON" output current @ Terminal OFF condi Solid Wire / Stranded Wire: \$\phi\$ Screwless to Screwless to "Volume", "Reset" Switch, "Clear" SAC Adaptor *1, Replacement plug (5 pcs.) | contact output (5VDC @ 1mA , Minimum, Reference) 0.41 - 0.81mm (AWG26 - 20) erminal block put NPN Transistor 4 6mA or less per cannel tion Voltage: 24VDC 0.41 - 0.81mm (AWG26 - 20) erminal block witch, "Mode" Switch, "Test" Switch *2, Installation Manual, Rubber feet (4pcs.) | |
| Num Co V External Co Num Co V V Operating | tact Output ber of Contacts ntact Capacity fire Diameter firing Method ntact Input ber of Contacts ntact Capacity fire Diameter firing Method portion ories | Non-voltage of (30VDC @ 3A) inrush current 5A or less Solid Wire / Stranded Wire: \$\phi\$ Screwless to Non-voltage contact in "ON" output current @ Terminal OFF condi Solid Wire / Stranded Wire: \$\phi\$ Screwless to Screwless to "Volume", "Reset" Switch, "Clear" SAC Adaptor *1, Replacement plug (5 pcs.) Wall Bracket (NH-WST2), T | contact output (5VDC @ 1mA , Minimum, Reference) 0.41 - 0.81mm (AWG26 - 20) erminal block put NPN Transistor 4 6mA or less per cannel tion Voltage: 24VDC 0.41 - 0.81mm (AWG26 - 20) erminal block witch, "Mode" Switch, "Test" Switch *2, Installation Manual, Rubber feet (4pcs.) | |
| External Co Num Co V V V V Operating | tact Output ber of Contacts ntact Capacity /ire Diameter /iring Method ntact Input ber of Contacts ntact Capacity /ire Diameter /iring Method portion ories on | Non-voltage of (30VDC @ 3A) inrush current 5A or less Solid Wire / Stranded Wire: \$\phi\$ Screwless to Non-voltage contact in "ON" output current @ Terminal OFF condi Solid Wire / Stranded Wire: \$\phi\$ Screwless to Screwless to "Volume", "Reset" Switch, "Clear" SAC Adaptor *1, Replacement plug (5 pcs.) | contact output (5VDC @ 1mA , Minimum, Reference) 0.41 - 0.81mm (AWG26 - 20) erminal block put NPN Transistor 4 6mA or less per cannel tion Voltage: 24VDC 0.41 - 0.81mm (AWG26 - 20) erminal block witch, "Mode" Switch, "Test" Switch *2, Installation Manual, Rubber feet (4pcs.) | |

| Drawing No. | | Page |
|--------------|---|--------|
| NHL-5FV2-W18 | F | 3 / 10 |

| | RoHS Directive (EN 50581) | |
|----------------------|--|--|
| | EMC Directive (EN 55032 (Class A), EN 55024) | |
| 0 () 0 1 | FCC Part15 Subpart B Class A, ICES-003 Class A | |
| Conformity Standards | UL 1638, UL 464, CSA C22.2 No.205 | |
| | KC (KN 61000-6-2, KN 61000-6-4) *3 | |
| | PSE Compliant AC Adaptor | |
| | *3 : Only N type and W type | |
| Remark | CE Marking | |
| | UL/cUL Listed | |
| | W type is an international model. | |

2. Model

2.1. Model Number Configuration



2.2. Model Number List

| NHL-1FV2-R | NHL-3FV2-RYG | NHP-1FV2-R | NHP-3FV2-RYG |
|-------------|----------------|-------------|----------------|
| NHL-1FV2-Y | NHL-3FV2N-RYG | NHP-1FV2-Y | NHP-3FV2N-RYG |
| NHL-1FV2-G | NHL-3FV2W-RYG | NHP-1FV2-G | NHP-3FV2W-RYG |
| NHL-2FV2-RY | NHL-4FV2-RYGB | NHP-2FV2-RY | NHP-4FV2-RYGB |
| NHL-2FV2-RG | NHL-5FV2-RYGBC | NHP-2FV2-RG | NHP-5FV2-RYGBC |
| | | | |

| Drawing No. | | Page |
|--------------|---|--------|
| NHL-5FV2-W18 | F | 4 / 10 |

3. Action Specification

3.1. Information (Main Unit)

| | | nation (Main Onit) | | | |
|------------------|--|-------------------------|---|--|--|
| Signal | Towe | r | Lighting pattern for each color LED units, | | |
| | | | such as continuous lighting, flashing pattern 1, and flashing pattern 2 | | |
| | Flasl | hing pattern 1 | ON(500ms), OFF(500ms) (repetition) | | |
| | Flasl | hing pattern 2 | ON(80ms), OFF(170ms), ON(80ms), OFF(670ms) (repetition) | | |
| Sound | | | Up to 70 types of messages can be played on the main unit speaker and line output. | | |
| | Num | ber of messages | Playlist Package: 30 kinds MP3 File: 30 kinds Preset: 10 kinds | | |
| | | MD2 Famasat | Bit Rate 32kbit/s, 64kbit/s (Standard Rate), 128kbit/s | | |
| | | MP3 Format | Constant Bit Rate (CBR) only | | |
| | | Preset | Buzzer Sound : 4 kinds Chime Sound : 3 kinds Voice Sound : 3kinds | | |
| | Play | back Pattern | One-shot Playback, Repeat Playback, Endless Playback | | |
| | One-shot Playback | | It is played back once per playback event. | | |
| | | Danast Dlaubasi. | It is played back when set up to play a certain number of times per playback event. | | |
| | Repeat Playback | | Number of playback times : 1 - 254 | | |
| | | Endless Playback | It will play back repeatedly per playback event. | | |
| | Play | back Mode | Input Priority Playback, Memory Playback | | |
| | | Innut Priority Playbook | If a new playback event occurs, the channel being played back | | |
| | | Input Priority Playback | will be interrupted and a new channel will play. | | |
| | | Memory Playback | When playback is ended, the next available channel stored in memory will play. | | |
| Buzzer | Buzzer Sound Buzzer pattern 1 Buzzer pattern 2 | | Four kinds of buzzer sounds, such as buzzer pattern1, 2, 3, and 4 | | |
| | | | ON(250ms), OFF(250ms) (repetition) | | |
| | | | ON(500ms), OFF(500ms) (repetition) | | |
| | | Buzzer pattern 3 | ON(200ms), OFF(50ms), ON(200ms), OFF(550ms) (repetition) | | |
| Buzzer pattern 4 | | | ON(continuity) | | |

3.2. External control

| Exter | nal Contact Output | External contact output can be controlled when an event occurs or outputting sound. |
|-------|--------------------|---|
| | Contact Function | Digital Output, BUSY Output |
| | Digital Output | The digital "A Contact" or "B Contact" output |
| | Digital Output | for an automatic OFF function of the digital output port can be set up. |
| | DLICV Output | It controls the relay contact output |
| | BUSY Output | in conjunction with the signal output from the line-out. |

3.3. Information (Network)

| Mail Tr | ransmission | When an event occurs, an e-mail message is transmitted to the registered address. | |
|---------|-------------------------|--|--|
| | Number of mail address | 8 | |
| | Authentication protocol | POP before SMTP, SMTP_AUTH | |
| | Security | SSL, TLS, none | |
| SNMP | TRAP Transmission | When an event occurs, TRAP transmission can be executed. | |
| | Number of transmission | 8 | |
| | Version | v2c | |
| SLMP | Write Command | When "Clear operation" occurs, SLMP Write Command can be executed. | |
| | Number of transmission | 4 | |
| | Protocol | SLMP (The same format as the QnA compatible 3E and 4E frame of MC protocol) TCP / UDP | |

| Drawing No. | Rev. | Page |
|--------------|------|--------|
| NHL-5FV2-W18 | F | 5 / 10 |

4. Function Specification

4.1. Main Unit Control Function

| RSH Command | Controllable with RSH Command | | |
|---|---|--|--|
| HTTP Command | Controllable with HTTP Command | | |
| Socket Communication | Controllable with PNS Command and PHN Command | | |
| SNMP Command | Controllable with SNMP "set" Command | | |
| Version v1 / v2c | | | |
| "Clear" Switch Clear operation is possible with "Clear" Switch of the main unit | | | |

| | | Controllable Action | | | | | | |
|----------------|--------------|---------------------|-------------|-------------|----------|-------------|-------------|----------|
| Comm | nand | Signal Tower | Sound | Buzzer | Digi-Out | e-mail | TRAP | SLMP |
| RSH Cor | nmand | ' | ✓ | ✓ | ✓ | ✓ *1 | ✓ *1 | - |
| HTTP Co | HTTP Command | | ✓ | V | ✓ | - | - | - |
| Socket | PNS | ' | ✓ | V | ✓ | - | - | - |
| Socker | PHN | △ *2 | - | △ *3 | - | - | - | - |
| SNMP Co | SNMP Command | | / | ✓ | ✓ | - | - | - |
| "Clear" Switch | | ✓ | ✓ *4 | ✓ *5 | ✓ | V | V | V |

^{*1 :} It can be used when e-mail or TRAP is set to "Active" in the RSH Command Configuration.

4.2. External Monitoring Function

| Ping Mo | onito | | Function | Network abnormality detection by sending Ping network devices | | | |
|---------|------------------|-------|--------------------|--|--|--|--|
| | Num | ıbe | r of Monitoring | 24 | | | |
| | Monitoring Cycle | | | 1 - 600 seconds | | | |
| | Sen | din | g Count | The number of times to detect can be set from 1 to 30. | | | |
| | Num | ıbe | r of Sending | The number of sending Ping by one monitoring can be set from 1 to 3. | | | |
| Applica | ition I | Mo | nitoring Function | External devices abnormality detection by receiving the data from them | | | |
| | Num | ıbe | r of Monitoring | 4 | | | |
| | Mon | itor | ing Cycle | 1 - 600 seconds | | | |
| SNMP | TRAI | P R | eception Function | TRAP Reception detection | | | |
| | Vers | ion | | v1 / v2c | | | |
| | Num | ıbe | r of Reception | 64 | | | |
| | varia | able | e-bindings | 2 OID per 1 TRAP Reception | | | |
| | | | Detectable Type | INTEGER | | | |
| | | | Detectable Type | OCTET STRING (String data, Binary data) | | | |
| SNMP | Supp | ort | ed Equipment | For SNMP Supported equipment, with the SNMP command, | | | |
| Monitor | r Fun | ctic | n | their status can be acquisitioned periodically and monitored. | | | |
| | Vers | ion | | v1 | | | |
| | Mon | itor | ing Cycle | 1 - 60 seconds | | | |
| | Dete | ectio | on method | Condition Agreement Detection : 20 Change Detection : 5 | | | |
| | | Co | ondition Agreement | Detection that the acquired value meets the condition | | | |
| | | | Detectable Type | INTEGER | | | |
| | | | Detectable Type | OCTET STRING (String data, Binary data) | | | |
| | | Cł | nange Detection | Detection that the acquired value has changed | | | |
| | | | Detectable Type | INTEGER | | | |

^{*2 :} Signal Tower "Red", "Amber"and "Green",and Flashing pattern 1

^{*3:} Buzzer pattern1 and Buzzer pattern 2

^{*4 :} In memory playback mode, you can proceed to the next message.

^{*5 :} It is possible to stop only the buzzer while maintaining the state of Signal Tower.

| Drawing No. | Rev. | Page |
|--------------|------|--------|
| NHL-5FV2-W18 | F | 6 / 10 |

| SLMP Read Command | Detects the state change of the device information of the PLC | | |
|------------------------|---|--|--|
| Number of Monitoring | 16 | | |
| Transmission Interval | 10ms / 50ms / 100ms | | |
| Drotocol | SLMP (The same format as the QnA compatible 3E and 4E frame of MC protocol) | | |
| Protocol | TCP / UDP | | |
| External Contact Input | It monitors the state change of external contact input. | | |
| Monitor Function | | | |
| Digital Logic Setting | A Contact, B Contact | | |
| Detection method | Status Change Detection, Status Agreement Detection | | |
| Status Change | Detection of change from OFF to ON or change from ON to OFF | | |
| Ctatus Assessment | Detecting the input for a certain period of time | | |
| Status Agreement | Detection time: 1 - 3600 seconds Number of Detection: 4 | | |

| | Executable action at detection | | | | | | |
|------------------------|--------------------------------|----------|----------|----------|----------|----------|------|
| Monitoring | Signal Tower | Sound | Buzzer | Digi-Out | e-mail | TRAP | SLMP |
| Ping Monitoring | ~ | V | ' | / | ✓ | V | - |
| Application Monitoring | ~ | V | ' | ~ | V | V | - |
| TRAP Reception | ~ | V | ' | ~ | V | V | - |
| SNMP Supported | ~ | V | ' | ~ | V | V | - |
| SLMP Command | ~ | V | ' | V | V | / | - |
| External Contact Input | ~ | V | V | ~ | V | V | - |

4.3. Main Unit Status Acquisition Function

| RSH Command | The state of the main body can be acquired by the status acquisition command. | | | |
|----------------------|--|--|--|--|
| Socket Communication | Status acquisition available with PNS Command and PHN Command | | | |
| SNMP Command | Status acquisition available with SNMP "get" Command | | | |
| Version | v1 / v2c | | | |
| HTTP Communication | By executing CGI, the state of the main body can be acquired in XML data format. | | | |
| Web browser | Download main unit status and event log with web browser | | | |
| web blowsel | Main Unit Status: XML format file Event Log: text format file | | | |
| USB Memory | Event log (text file) can be downloaded to USB memory | | | |

| | | Acquisition data | | | | |
|--------------|----------|------------------|----------|-------------|----------|-----------|
| Comm | and | Signal Tower | Sound | Buzzer | Ex-Input | Ex-Output |
| RSH Cor | nmand | V | V | / | ' | ✓ |
| Socket | PNS | ~ | - | / | - | - |
| Socket | PHN | ✓ *1 | - | ✓ *2 | - | - |
| SNMP Command | | ~ | V | V | ' | V |
| XML forr | nat file | ✓ | V | V | ✓ | V |

^{*1 :} Signal Tower "Red", "Amber"and "Green",and Flashing pattern 1
*2 : Buzzer pattern 1 and Buzzer pattern 2

| Drawing No. | Rev. | Page |
|--------------|------|--------|
| NHL-5FV2-W18 | F | 7 / 10 |

4.4. Main Unit Setting Function

| Schedule Function | The time period for disabling the notification operation can be set. | | |
|-----------------------------|---|--|--|
| Suspended operations | "Signal Tower", "Sound and Buzzer", "Digital Output" ,"Trap Transmission" | | |
| Time period of the schedule | "24 hours" or "Three time periods per day" | | |
| Time Correction Function | The internal clock in this product can communicate with an NTP server | | |
| Time Correction Function | to automatically correct the time. | | |
| Automatic Network Setting | Network setting in this product can communicate with an DHCP server | | |
| Automatic Network Setting | to automatically set. | | |
| Master Volume Setting | Mstar Volume of Buzzer and sound can be set | | |
| Standard Action Setting | This product can set lighting color of the Signal Tower after clear operation is execut | | |
| Self-test Function | Self test of Signal Tower and buzzer is possible | | |
| Self-lest Function | with test switch of the main body and RSH command. | | |
| Config Setting | Various settings of the main body can be read and written as setting file. | | |
| Main Unit Setting | Various settings of the main body can be done with a web browser. | | |
| USB memory support | By using the USB memory, the following items can be executed by the main body only | | |
| Config File | Various settings of the main unit can be read and written as a config file. | | |
| Playlist Package | You can set the playlist package created with PATLITE Playlist Editor 2 | | |
| Event Log | It is possible to acquire an event log that records the operation history of the main unit. | | |
| Firmware update | It is possible to update firmware. | | |
| Setting Supported languages | Japanese, English | | |

4.5. Cloud Function

| Sun | Supported Cloud Platform | | Microsoft Azure *1 | | | |
|------|------------------------------|---------------------|---|--|--|--|
| Sup | | | Amazon Web Services (AWS) *2 | | | |
| | | Connection Settings | Azure IoT Central/DPS,Azure IoT Hub | | | |
| | Azure | Built-in features | Device Twin、Direct Method、Device-to-cloud Message、 | | | |
| | | Dulit-III leatures | Cloud-to-device Message | | | |
| | AWS | Connection Settings | AWS IoT Core | | | |
| | AVVO | Built-in features | Device Shadow, MQTT client | | | |
| | Main Unit Control | | Signal Tower,Sound,Buzzer,Digi-Out | | | |
| ı | Main Unit Status Acquisition | | Signal Tower,Sound,Buzzer,Digi-Out | | | |
| M | ain Unit Stat | us Transmission | Signal Tower, Sound, Buzzer, "Clear" switch, External Contact Input, Digi-Out | | | |
| 44 8 | | | | | | |

^{*1} Microsoft, and Azure are registered trademarks of Microsoft Corporation in the United States and other contries.

^{*2} Amazon Web Services, the "Powered by AWS" logo, and name any other AWS Marks used in such materials are trademarks of Amazon.com, Inc. or its affiliates in the United States and/or other countries.

